



COMPUTER PIN INFORMATION

1	
2	VCM VALVE - IDLE SPEED CONTROL
3	
4	VCM VALVE - EGR CONTROL
8	IGNITION COIL TRANSISTOR
9	CRUISE CONTROL
7	
8	CRANK ANGLE - DISTRIBUTOR - 1 DEGREE
9	CRANKING VOLTS - STARTER SWITCH
10	NEUTRAL SWITCH
11	CHECK CONNECTOR
12	
13	
14	
15	
16	FUEL PUMP RELAY - RELAY TERMINAL 86
17	CRANK ANGLE - DISTRIBUTOR - 180 DEGREES
18	THROTTLE SWITCH - FULL THROTTLE
19	
20	
21	KNOCK SENSOR SIGNAL
22	AIR CONDITIONER
23	WATER TEMPERATURE SENSOR
24	OXYGEN SENSOR
25	THROTTLE SWITCH - IDLE
26	AIR FLOW METER
27	12 VOLTS TO COMPUTER, VCM & DISTRIBUTOR FROM RELAY TERMINAL 87
28	ENGINE EARTH - CHECK CONNECTOR 92 - DISTRIBUTOR
29	SPEED SENSOR
30	INTAKE AIR TEMPERATURE SENSOR - AIR FLOW METER
31	AIR FLOW METER
32	
33	AIR FLOW METER
34	
35	
36	12 VOLTS FROM PIN 27
38	EARTH FROM PIN 28
101	INJECTOR No. 1
102	INJECTOR No. 2
104	INJECTOR No. 3
106	INJECTOR No. 4
107	INJECTOR EARTH
108	AIR REGULATOR EARTH
109	INJECTOR EARTH
112	INJECTOR EARTH
113	INJECTOR EARTH
45	AIR REGULATOR 12 VOLTS FROM FUEL PUMP RELAY
58	CONNECTOR PIN - 12 VOLTS FROM FUSIBLE LINK
72	TO TEMPERATURE GAUGE FROM SENDER
158	CRUISE CONTROL